

# PARTA

# Part A Liquid



### BENEFITS

- ♦ Specifically designed to be blended with all FirmeCrete® Coatings
- ♦ Adds Strength without Adding stickiness to the Coatings
- \* Easily diluted with water
- Strong enough to take on Vehicular Traffic in 72 Hours

SCAN QR CODE FOR MIXING INSTRUCTIONS:



# **Product Data Sheet**

**Description:** FirmeCrete® PART A Liquid was designed & specifically formulated to be blended with FirmeCrete® Floor & Wall coatings. FirmeCrete® PART A Liquid was designed to add the perfect amount of strength to the FirmeCrete® Floor & Wall coatings system without creating a sticky, hard to trowel coating. The Part A Liquid is strong enough to take on Surface Retardants & FirmeCrete's® Concrete Etcher, yet when added to our Floor & Wall Coating Systems the final thickness is only 1/8"-1/2".

**Uses:** FirmeCrete® PART A Liquid is to be diluted and blended with FirmeCrete® Floor & Wall Coating Systems.

# Mixing PART A Liquid:

**Step 1:** In a separate mixing container add 144 ounces (4.5 quarts) of Clean Potable Water.

\*Step 2: Add all of the Part A Concentrate to the 144 oz. (4.5 quarts) of water. Make sure you get all of the Part A out of its container.

**Step 3:** Blend the Part A & water mixture with a Jiffy Mixture or Paint Mixer attached to a low speed drill until uniform consistency. The end result will be 168 oz. (5.25 quarts) of ready to use Part A Water Mixture.

**Step 4:** Add as much of the Part A Water Mixture to the Part B powder until you reach your desired consistency.

## \*For Vehicular Traffic Coatings:

Add (2) Part A Concentrate Containers to 120 ounces (3.75 quarts) of Clean Potable Water. Then Follow Steps 3 & 4 above.

If the Part A Water Mixture sits overnight Make Sure to reblend Mixture because the Part A Concentrate may have settled.